

Stop Leak for Auto

Directions for Use in MOST Cases

As per use with any refrigerant product, take adequate precautions during use.

Use with Mineral, Ester & Pag Oils Only!

- 1. Shake can well.
- 2. Install can tap valve and charging hose.
- 3. Install charging hose on low pressure side.
- 4. Invert can.
- 5. Install all product from can.
- 6. Fill system to manufacturer specification pressure.
- 7. Run compressor to circulate.
- 8. Discard empty can according to all rules and regulations for disposal in your area.

Note: If an air conditioning system charged with Enviro-Safe develops a leak, it is recommended to evacuate any refrigerant before adding any dye charge, oil charge or before installation of any refrigerant.