

**ENVIRO-SAFE 134A REPLACEMENT
REFRIGERANT W/DYE
PRESSURE TEMPERATURE CHART**

TEMP			ES	R134a
C	F		Psi	Psi
-40	-40		-4	-7
-38	-36		-3	-6
-36	-33		-2	-6
-34	-29		-1	-4
-32	-26		0	-3
-30	-22		1	-2
-28	-18		3	-1
-26	-15		4	1
-24	-11		6	2
-22	-8		7	4
-20	-4		9	6
-18	0		11	7
-16	3		12	9
-14	7		14	10
-12	10		16	13
-10	14		19	15
-8	18		21	17
-6	21		23	20
-4	25		26	22
-2	28		28	25
0	32		31	28
2	36		34	31
4	39		37	33
6	43		41	37
8	46		44	41
10	50		48	46
12	54		51	50
14	57		55	54
16	61		59	59
18	64		63	64
20	68		68	68
22	72		72	74
24	75		77	79
26	79		82	85
28	82		87	91
30	86		92	97
32	90		98	104
34	93		104	111
36	97		109	118
38	100		115	126
40	104		122	133
42	108		129	142
44	111		135	150
46	115		142	159
48	118		150	168
50	122		157	177
52	126		165	188
54	129		173	198
56	133		181	208

